

Compact Motorized Cylinder

DR Series Table type

OPERATING MANUAL Actuator Edition

Table of contents

1	Introduction	2	7	Inspection and maintenance ...	39
2	Safety precautions	4	8	Troubleshooting	43
3	Precautions for use.....	7	9	Specifications	44
4	Preparation	12	10	Regulations and standards.....	49
5	Installation	17	11	Accessory	50
6	Connection	37	12	Dimensions	51

Thank you for purchasing an Oriental Motor product.
This Manual describes product handling procedures and safety precautions.

- Please read it thoroughly to ensure safe operation.
- Always keep the manual where it is readily available.

1 Introduction

1-1 Before use

Only qualified personnel of electrical and mechanical engineering should work with the product.

Use the product correctly after thoroughly reading the section "2 Safety precautions" on p.4. In addition, be sure to observe the contents described in warning, caution, and note in this manual.

The products described in this manual is designed and manufactured to be incorporated in general industrial equipment. Do not use for any other purpose. Oriental Motor Co., Ltd. is not responsible for any compensation for damage caused through failure to observe this warning.

1-2 Overview of the product

The compact motorized cylinder **DR** Series (hereinafter described as cylinder) is an actuator of a linear motion mechanism that a stepping motor is integrated with a ball screw.

The following two types of motors are provided.

- 2-Phase Stepping Motor **PKP** Series
- **αSTEP AZ** Series

1-3 Related operating manuals

For operating manuals, download from Oriental Motor Website Download Page or contact your nearest Oriental Motor sales office.

■ Cylinder equipped with the PKP Series

- **DR** Series OPERATING MANUAL Actuator Edition (this document)
- Motorized actuator Compact Motorized Cylinder Function Setting Edition *

* Be sure to read the operating manual "Function Setting Edition" which is exclusively for compact motorized cylinders.

Refer to the operating manual of the driver for contents not described in these manuals.

■ Cylinder equipped with the **AZ** Series

- **DR** Series OPERATING MANUAL Actuator Edition (this document)
- **AZ** Series/Motorized actuator equipped with **AZ** Series OPERATING MANUAL Function Edition
- Motorized actuator Compact Motorized Cylinder Function Setting Edition *

* Be sure to read the operating manual "Function Setting Edition" which is exclusively for compact motorized cylinders.

Refer to the operating manual of the driver for contents not described in these manuals.




2 Safety precautions

The precautions described below are intended to ensure the safe and correct use of the product, and to prevent the customer and others from exposure to the risk of injury. Use the product only after carefully reading and fully understanding these instructions.



You must not operate the cylinder (operate the equipment for the specified purpose) if the machine in which the cylinder is installed does not satisfy the related safety standards. The factory safety manager or safety personnel in charge of the applicable machine must ensure that the machine is operated only by qualified personnel who are familiar with the operation of electronic equipment, and thereby prevent injury or damage to the equipment.

The term “qualified personnel” refers to persons who have received the necessary training or education and have pertinent experience; who are familiar with the relevant standards, regulations, accident-prevention rules and inspection conditions; who are authorized by the factory safety manager to engage in the necessary activities; and who have the ability to discern and prevent potential dangers.



Description of signs

 WARNING	Handling the product without observing the instructions that accompany a “WARNING” symbol may result in serious injury or death.
 CAUTION	Handling the product without observing the instructions that accompany a “CAUTION” symbol may result in injury or property damage.
 Note	The items under this heading contain important handling instructions that the user should observe to ensure the safe use of the product.




Description of graphic symbols

	Indicates “prohibited” actions that must not be performed.
	Indicates “compulsory” actions that must be performed.

⚠ WARNING

	<ul style="list-style-type: none"> • Do not use the cylinder in explosive or corrosive environments, in the presence of flammable gases, in places subjected to splashing water, or near combustibles. Doing so may result in fire or injury. • Do not transport, install, connect or inspect the cylinder while the power is supplied. Doing so may result in electric shock. • Do not forcibly bend, pull or pinch the cable. Doing so may result in fire. • Do not disassemble or modify the cylinder. Doing so may result in injury or damage to equipment. • Never use the cylinder in a medical device used in connection with the maintenance or management of human life or health, or in a transportation system whose purpose is to move or carry people. • Be sure to provide a safety cage conforming to EN ISO 13857 to prevent persons from entering the moving range of the cylinder while power is supplied to the cylinder. Turn off the main power to the driver before performing adjustment or inspection in which the moving part is moved manually. Failure to do so may result in injury. • Do not hit the ball screw with the mechanical stopper in operations other than push-motion operation. Doing so may result in injury or damage to equipment.
	<ul style="list-style-type: none"> • Assign qualified personnel to the task of installing, wiring, operating/controlling, inspecting and troubleshooting the cylinder. Failure to do so may result in fire, injury or damage to equipment. • When setting the data, do so outside the safety cage. Failure to do so may result in injury. • Take measures to keep the moving part in position if the cylinder is used in vertical operations such as elevating equipment. Failure to do so may result in injury or damage to equipment. • When an alarm is generated in the driver (any of the driver's protective functions is triggered), take measures to hold the moving part in a specific position since the cylinder stops and loses its holding torque. Failure to do so may result in injury or damage to equipment. • Install the cylinder inside an enclosure. Failure to do so may result in injury. • Provide an emergency stop device or emergency stop circuit external to the equipment so that the entire equipment will operate safely in the event of a system failure or malfunction. Failure to do so may result in injury. • After replacing the driver, set the resolution, traveling direction or other parameters before operating the cylinder. If the cylinder is operated without setting parameters, the ball screw may move to unexpected directions or run at unexpected speeds, causing injury or damage to equipment.

⚠ CAUTION

	<ul style="list-style-type: none"> • Do not use the cylinder beyond its specifications. Doing so may result in injury or damage to equipment. • Keep your fingers and objects out of the openings in the cylinder. Failure to do so may result in fire or injury. • Do not touch the cylinder during operation or immediately after stopping. Doing so may result in a skin burn(s). • Do not carry the cylinder by holding the moving part or cable. Doing so may cause injury. • Keep the area around the cylinder free of combustible materials. Failure to do so may result in fire or a skin burn(s). • Do not leave anything around the cylinder that would obstruct ventilation. Doing so may result in damage to equipment. • Do not touch the moving part during operation. Doing so may result in injury. • Do not touch the terminals while conducting the insulation resistance measurement or the dielectric strength test. Doing so may result in electric shock. • While the cylinder is operated, do not make the cable contact with the moving part. Doing so may result in disconnection in the cable, leading to damage.
	<ul style="list-style-type: none"> • Use the cylinder and driver only in the specified combination. Failure to do so may result in fire. • Wear a helmet, safety shoes, gloves or other protective gear when transporting or installing the cylinder. Failure to do so may result in injury. • The motor surface temperature may exceed 70 °C (158 °F) even under normal operating conditions. If the operator is allowed to approach the cylinder in operation, affix a warning label shown in the figure on a conspicuous position. Failure to do so may result in a skin burn(s). <div style="text-align: right; margin-top: 20px;">  Warning label </div>

3 Precautions for use

This chapter covers restrictions and requirements the user should consider when using the product.

■ General

- **Be sure to use our cable to connect the cylinder and driver.**

Check on the Oriental Motor Website for the model name of cables.

- **Do not remove the stopper attached to the ball screw.**

Doing so may result in damage to the ball screw.

- **Do not detach the table or loosen the screws.**

If the table is detached or the screws secured the table is loosened, the installation accuracy of the ball screw to decrease, resulting in malfunction or shorter service life of the cylinder.

In the case of the cylinder equipped with the **AZ** Series, the home set in the encoder (ABZO sensor) at the time of shipment may be deviated, and this may cause unexpected movements, leading to damage to equipment.

- **Do not install a guide for load transportation additionally on the customer side.**

Misalignment of guides may cause damage to equipment.

- **When conducting the insulation resistance measurement or the dielectric strength test, be sure to separate the connection between the cylinder and the driver.**

Conducting the insulation resistance measurement or dielectric strength test with the cylinder and driver connected may result in damage to the product.

- **Do not make an impact on the cylinder.**

Do not drop the cylinder. Also, do not hit or strike the cylinder. Making an impact on the cylinder may cause the positioning accuracy to decrease, the cylinder to damage, or the lifetime to reduce.

- **For cylinder with adjusting knob**

Use the adjusting knob to adjust the position manually while the power is turned off. Rotating the adjusting knob by one revolution moves by a lead amount of the ball screw. Adjust the position within the effective stroke range of the cylinder.

Do not touch the adjusting knob during operation. Doing so may cause the cylinder to malfunction or damage.

■ Temperature

- **Use the cylinder equipped with the PKP Series in conditions where the motor surface temperature does not exceed 90 °C (194 °F).**

The motor does not have a function to protect from overheating. The motor surface temperature may exceed 90 °C (194 °F) under certain conditions (ambient temperature, operating speed, duty cycle, etc.). In order to prevent the bearings (ball bearings) of the motor from reaching its usable life quickly, use the cylinder in conditions where the motor surface temperature does not exceed 90 °C (194 °F).

- **Use the cylinder equipped with the AZ Series in conditions where the motor surface temperature does not exceed 80 °C (176 °F).**

The motor surface temperature may exceed 80 °C (176 °F) under certain conditions (ambient temperature, operating speed, duty cycle, etc.). In order to protect the encoder (ABZO sensor), use the cylinder in conditions where the motor surface temperature does not exceed 80 °C (176 °F).

If the encoder (ABZO sensor) temperature reaches the upper limit, the motor overheat protection alarm will generate.

- **Operate the cylinder in the range of the operating ambient temperature.**

If the cylinder is used outside of the operating ambient temperature, it may not operate properly.

- **When the our home-sensor set is used**

Use the home-sensor set in conditions where the motor surface temperature does not exceed 55 °C (131°F).

■ Operation

- **Set the wiring distance between the cylinder and driver to less than the specification value.**

Set to 10 m (32.8 ft.) or less for the cylinder equipped with the PKP Series and to 20 m (65.6 ft.) or less for the cylinder equipped with the AZ Series.

Exceeding the specification value may cause the thrust to reduce.

- **Holding torque at standstill**

The holding force at standstill for the cylinder is a value when the current cutback function (stop current 50 %) is enabled. Note the holding force is reduced in the current cutback state. In addition, turning off the power supply causes the holding force of the cylinder to lose. Make sure a load does not fall.

- **With the cylinder equipped with the AZ Series, do not perform push-motion operation at the speed exceeding the maximum push speed or the maximum push-motion return-to-home speed.**

The mechanical impact may cause damage to the cylinder. If the ball screw was pressed at high speed, take measures by referring to "8 Troubleshooting" on p.43.

- **Push-motion operation can be performed with the DR28 cylinder of ball screw lead 2.5 mm equipped with the AZ Series.**

Do not perform push-motion operation with the cylinder of ball screw lead 1 mm equipped with the **AZ** Series. The TLC output may be turned ON before push-motion operation is complete. (Push-motion return-to-home operation can be performed.)

■ Inspection


● Grease

Grease on the ball screw or linear guide may darken during the initial operation (one to three weeks). Refer to p.40, and wipe off the dirty grease to apply new grease.

3-1 Notes about using the cylinder equipped with the AZ Series

● Make sure not to hit or apply a strong impact on the encoder (ABZO sensor).

- Making a strong impact on an encoder (ABZO sensor) may cause the cylinder malfunction or damage to the encoder (ABZO sensor).
- When transporting the cylinder or installing a load, handle the cylinder carefully not to make a strong impact on the moving part.
- The warning label shown in the figure is indicated on the cylinder.



Warning label

● Do not move the encoder (ABZO sensor) toward a strong magnetic field.

A magnetic sensor is built into the encoder (ABZO sensor). If the cylinder is installed close to equipment which generates a strong magnetic field, the encoder (ABZO sensor) may break or malfunction. Keep the magnetic flux density on the surface of the encoder (ABZO sensor) so as not to exceed the values in the table. Check the manufacturing date of the cylinder with the nameplate.

Cylinder manufacturing date	Magnetic flux density	
	When transporting and storing	When operating
After October 2023	10 mT	10 mT
Before September 2023	5 mT	2 mT *

* When the magnetic flux density is exceeding 1 mT and 2 mT or less, use in an environment where the operating ambient temperature is exceeding 20 °C (68 °F) and 40 °C (104 °F) or less.

● Meshing noise of mechanical sensor

A gear type mechanical sensor is built into the encoder (ABZO sensor). Although the meshing noise of gears may generate, it is not malfunction.


3-2 Notes when the connection cable is used

Note the following points when our cable is used.

■ Cylinder equipped with the PKP Series


● When inserting the connector

Hold the connector main body, and insert it in straight securely. Inserting the connector in an inclined state may result in damage to connector or a connection failure.



● When pulling out the connector

Pull out the connector in straight. Pulling out the connector with holding the lead wire may result in damage to the connector.



Secure the lead wires at the connection part of the connector to prevent the connector or terminals from receiving stress due to bending or self-weight of lead wires. Also, do not excessively bend the lead wires near the connection part of the connector. Applying stress on the lead wires may cause poor contact or disconnection, leading to malfunction or heat generation.

■ Cylinder equipped with the AZ Series

● When inserting the connector


Hold the connector main body, and insert it in straight securely. Inserting the connector in an inclined state may result in damage to terminals or a connection failure.

● When pulling out the connector

Pull out the connector in straight while releasing the lock part of the connector. Pulling out the connector with holding the cable may result in damage to the connector.


● Bending radius of cable

Use the cable in a state where the bending radius of the cable is more than six times of the cable diameter. Do not bend the lead wires part or fix it with a clamp. Doing so may cause damage to the connector.



● How to fix the cable

Fix the cable near the connectors at two places as shown in the figure or fix it with a wide clamp to take measures to prevent stress from being applied to the connectors.



4 Preparation

4-1 Checking the product

Verify that the items listed below are included. Report any missing or damaged items to the Oriental Motor sales office from which you purchased the product.

- Compact motorized cylinder 1 unit
- Instructions and Precautions for Safe Use..... 1 copy


4-2 How to identify the product model

Verify the model name of the purchased against the number shown on the nameplate.

DR **28** **T** **2.5** **BC** **03** - **P2** **A** **K** **R** **-F**
1 2 3 4 5 6 7 8 9 10 11


1	Series	DR: DR Series
2	Frame size	20: 20 mm 28: 28 mm
3	Type	T: Table type
4	Ball screw lead	1: 1 mm 2.5: 2.5 mm
5	Ball screw type	A: Rolled ball screw AC: Rolled ball screw with cover B: Precision ball screw BC: Precision ball screw with cover
6	Stroke	02: 25 mm 03: 30 mm
7	Equipped motor	P2: PKP Series AZ: AZ Series
8	Additional function	A: None N: With adjusting knob
9	Motor power supply type	K: DC power supply input
10	Cable outlet direction *	D: Downward direction R: Right direction L: Left direction
11	Mounting plate	Blank: Without mounting plate -P: With foot -F: With flange

* The cable outlet direction represents the direction as viewed from the opposite side of the ball screw in a state of placing the side face mounting sections downward.



4-3 Information about nameplate

The figure shows an example.



4-4 Driver for possible combinations

Use the **DR** Series in combination with the drivers shown in the table.


Equipped motor	Driver combination
PKP Series	CVD215BR-K, CVD215B-K, CVD215-K
AZ Series	DC power input driver

4-5 Names of parts


The areas indicated in gray color represent a moving part.

■ Cylinder equipped with the PKP Series

The figure shows the **DR28** with adjusting knob.




* This prevents the ball screw from retracting completely into the motor.




■ Cylinder equipped with the AZ Series

The figure shows the **DR28**.




* This prevents the ball screw from retracting completely into the motor.



* **DR28** only.


■ With ball screw cover

The figure shows the **DR28** equipped with the **PKP** Series.




■ With foot

The figure shows the **DR28** equipped with the **PKP** Series.



■ With flange

The figure shows the **DR28** equipped with the **PKP** Series.



In the case of the cylinder with flange equipped with the **AZ** Series, a cylinder which cable outlet direction is right or left cannot be installed by putting in from the front face of the mounting plate. (⇒ p.28)

5 Installation

5-1 Installation location

The cylinder is designed and manufactured to be incorporated in equipment. Install it in a well-ventilated location that provides easy access for inspection. The location must also satisfy the following conditions:

- Inside an enclosure that is installed indoors (provide vent holes)
- Operating ambient temperature: 0 to +40 °C [+32 to +104 °F] (non-freezing)
- Operating ambient humidity: 85 % or less (non-condensing)
- Area free of explosive atmosphere or toxic gas (such as sulfuric gas) or liquid
- Area not exposed to direct sun
- Area free of excessive amount of dust, iron particles or the like
- Area not subject to splashing water (rain, water droplets), oil (oil droplets) or other liquids
- Area free of excessive salt
- Area not subject to continuous vibrations or excessive shocks
- Area free of excessive electromagnetic noise (from welders, power machinery, etc.)
- Area free of radioactive materials, magnetic fields or vacuum
- Up to 1,000 m (3,300 ft.) above sea level

5-2 Installation overview

The cylinder can be installed in any direction.

Install the cylinder onto an appropriate flat mounting plate or base plate [thickness approximately 5 mm (0.2 in.) or more] having excellent vibration resistance and heat conductivity. If a high accuracy is required, design the thickness of the plate in consideration of installation conditions such as load condition, rigidity, vibration, and others.

Values of the tightening torque are recommended. Tighten with an appropriate torque according to the design conditions of the mounting plate, base plate, and load.

There are four installation methods, front mounting, side face mounting, mounting using the foot, and mounting using the flange.

5-3 Notes when the cylinder equipped with the AZ Series is installed

■ If the cylinder is installed in an environment where a magnetic field is generated

A magnetic sensor is built into the encoder (ABZO sensor). If the cylinder is installed close to equipment which generates a strong magnetic field, the encoder (ABZO sensor) may break or malfunction. Ensure that the magnetic flux density on the surface of the encoder (ABZO sensor) does not exceed the value in the table. Check the manufacturing date of the cylinder with the nameplate.

Cylinder manufacturing date	Magnetic flux density
After October 2023	10 mT
Before September 2023	2 mT *

* When the magnetic flux density is exceeding 1 mT and 2 mT or less, use in an environment where the operating ambient temperature is exceeding 20 °C (68 °F) and 40 °C (104 °F) or less.




Do not install the cylinder close to equipment which generates a strong magnetic field.

■ Installing the cylinder equipped with the AZ Series

The encoder (ABZO sensor) of the cylinder equipped with the **AZ** Series is easily affected by a magnetic field, so make sure the installation location.

When installing the cylinders side by side, allow the distance shown in the table or more around the encoder (ABZO sensor). Check the manufacturing date of the cylinder with the nameplate.

Cylinder manufacturing date	Distance from ABZO sensor (L)
After October 2023	2 mm
Before September 2023	Frame size




5-4 Installation method by front mounting

Secure the cylinder to a mounting plate.

■ Design for mounting plate [Unit: mm]


The figure shows the recommended design dimensions of a mounting plate required when the cylinder is installed. Provide a through hole of the flange pilot and a space for passing the stopper (ball screw cover) to the mounting plate.



Model	C	øD	øE	F	G
DR20	16±0.1	ø2.3	ø16 $^{+0.018}_0$	11	11.5
DR28	23±0.1	ø3	ø22 $^{+0.021}_0$	15	16

■ Specification of mounting holes of cylinder


Details of **DR20** mounting hole



Model	Nominal size	Tightening torque	Mounting holes dimension (mm)		
			øM	L0	L (Effective depth of screw thread)
DR20	M2	0.4 N·m (56 oz-in)	ø2.3	2	5
DR28	M2.5	0.5 N·m (71 oz-in)	—	—	5

■ Installation method

Install the pilot of the cylinder to the flange pilot, and secure the mounting holes with screws (not included). The figure shows the **DR28**.



Note

Do not detach the table or loosen the screws of the table. Doing so may decrease the installation accuracy of the ball screw, resulting in malfunction or shorter service life of the cylinder. In the case of the cylinder equipped with the **AZ** Series, the home set in the encoder (ABZO sensor) at the time of shipment may be deviated, and this may cause unexpected movements, leading to damage to equipment.


5-5 Installation method by side face mounting

Secure the cylinder to a base plate using the side face mounting sections.

When the cylinder is installed in a state where the cable or connector is placed in the downward direction, design the mounting position and base plate so that the cable or connector does not contact the base plate.

■ Design for base plate


When the positioning pins are installed on the base plate, design so that the height of the positioning pins are below the specified value in the figure from the top surface of the base plate.




Note Make sure that the height of the positioning pins are below the specified value in the figure from the top surface of the base plate. Exceeding the specified value may cause the cylinder to break, leading to injury or mechanical damage.

■ Specifications of positioning pin holes of cylinder [Unit: mm]


● DR20



● DR28



Details of section A



Model	Recommended size of positioning pin	Positioning pin hole (round hole)		Positioning pin hole (elongated hole)		
		Diameter	Depth	E	F	Depth
DR20	$\varnothing 2 \begin{smallmatrix} 0 \\ -0.01 \end{smallmatrix}$	$\varnothing 2 \begin{smallmatrix} +0.02 \\ 0 \end{smallmatrix}$	3	$2 \begin{smallmatrix} +0.02 \\ 0 \end{smallmatrix}$	1	3
DR28	$\varnothing 3 \begin{smallmatrix} 0 \\ -0.01 \end{smallmatrix}$	$\varnothing 3 \begin{smallmatrix} +0.01 \\ 0 \end{smallmatrix}$	2.5	$3 \begin{smallmatrix} +0.01 \\ 0 \end{smallmatrix}$	1	2.5

■ Specifications of mounting holes of cylinder

Model	Nominal size	Tightening torque	Effective depth of screw thread
DR20	M2.5	0.5 N·m (71 oz-in)	3.5 mm
DR28	M3	1 N·m (142 oz-in)	3.5 mm


■ Installation method

The figure shows the **DR28**.

1. Install the positioning pins on the base plate.

Note Be sure to install the positioning pins on the base plate. Pressing the positioning pins into the cylinder may cause damage.

2. Install the cylinder while the positioning pins are inserted into the positioning pin holes of the cylinder, and secure the mounting holes with screws (not included).



Note Do not detach the table or loosen the screws of the table. Doing so may decrease the installation accuracy of the ball screw, resulting in malfunction or shorter service life of the cylinder. In the case of the cylinder equipped with the **AZ** Series, the home set in the encoder (ABZO sensor) at the time of shipment may be deviated, and this may cause unexpected movements, leading to damage to equipment.

5-6 Mounting using the foot

Secure the foot to a base plate.

When the cylinder is installed in a state where the cable or connector is placed in the downward direction, design the mounting position and base plate so that the cable or connector does not contact the base plate.


■ Specifications of mounting holes of foot

Model	Nominal size	Tightening torque
DR20	M2.5	0.5 N·m (71 oz-in)
DR28	M3	1 N·m (142 oz-in)

■ Specifications of positioning pin holes of foot [Unit: mm]

The figure shows the **DR28**.

Model	Recommended size of positioning pin	Thickness of foot
DR20	$\varnothing 3 \begin{smallmatrix} 0 \\ -0.01 \end{smallmatrix}$	5
DR28		8.5



■ Installation method


The figure shows the **DR28**.

1. Install the positioning pins on the base plate.



Be sure to install the positioning pins on the base plate. Pressing the positioning pins into the cylinder may cause damage.

2. Install the foot while the positioning pins are inserted into the positioning pin holes of the foot, and secure the mounting holes with screws (not included).



Do not detach the table or loosen the screws of the table. Doing so may decrease the installation accuracy of the ball screw, resulting in malfunction or shorter service life of the cylinder. In the case of the cylinder equipped with the **AZ** Series, the home set in the encoder (ABZO sensor) at the time of shipment may be deviated, and this may cause unexpected movements, leading to damage to equipment.

5-7 Mounting using the flange

Secure the cylinder to a mounting plate from the front face or rear face of the flange.

■ Design for mounting plate [Unit: mm]


The following shows the recommended design dimensions of a mounting plate required when the cylinder is installed.

When using our home-sensor set, design the mounting plate so that the sensor does not contact it.

● When mounting from the front face


Cylinder equipped with the PKP Series

Provide a space for passing the connector according to the cable outlet direction.



* It is a space for passing the connector.


Cylinder equipped with the AZ Series



Model	C	D	E	F	G	H
DR20	11	16±0.1	8±0.1	31±0.1	22	4×M2
DR28	15	23±0.1	11.5±0.1	48±0.1	30	4×M3

● When mounting from the rear face

Provide a space for passing the stopper (ball screw cover) to the mounting plate.



Model	C	D	E	F	H	I
DR20	11	16±0.1	8±0.1	31±0.1	4×M2	22
DR28	15	23±0.1	11.5±0.1	48±0.1	4×M3	29


■ Specification of mounting holes of flange

Model	Nominal size	Tightening torque
DR20	M2	0.4 N·m (56 oz-in)
DR28	M3	1 N·m (142 oz-in)

■ Specification of positioning pin holes of flange [Unit: mm]

The figure shows the **DR28**.

Model	Recommended size of positioning pin	Thickness of flange
DR20	$\varnothing 3 \begin{smallmatrix} 0 \\ -0.01 \end{smallmatrix}$	5
DR28		8



■ Installation method


All figures show the **DR28**.

1. Install the positioning pins on the mounting plate.


Note Be sure to install the positioning pins on the mounting plate. Pressing the positioning pins into the cylinder may cause damage.

2. Mount the flange while inserting the positioning pins into the positioning pin holes of the flange, and secure the mounting holes with screws (not included).

- When putting the cylinder in from upward and securing from the front face with screws




- When putting the cylinder in from the front face of the mounting plate and securing from the front face with screws



Note The cylinder equipped with the **AZ** Series cannot be installed by putting in from the front face of the mounting plate because the ABZO sensor of the cylinder which cable outlet direction is right and left contacts the mounting plate.

- When mounting from the rear face



Note

Do not detach the table or loosen the screws of the table. Doing so may decrease the installation accuracy of the ball screw, resulting in malfunction or shorter service life of the cylinder. In the case of the cylinder equipped with the **AZ** Series, the home set in the encoder (ABZO sensor) at the time of shipment may be deviated, and this may cause unexpected movements, leading to damage to equipment.

5-8 Installing a load

There are two load mounting surfaces, which are provided on the linear guide side and the ball screw side. All figures show the **DR28**.


■ When using load mounting surface in the linear guide side

● Specification of load mounting holes

Model	Nominal size	Tightening torque	Effective depth of screw thread
DR20	M2	0.4 N·m (56 oz-in)	4 mm
DR28	M3	1 N·m (142 oz-in)	6 mm

● Installation method


Secure the load with screws (not included).



Note Do not detach the table or loosen the screws of the table. Doing so may decrease the installation accuracy of the ball screw, resulting in malfunction or shorter service life of the cylinder. In the case of the cylinder equipped with the **AZ** Series, the home set in the encoder (ABZO sensor) at the time of shipment may be deviated, and this may cause unexpected movements, leading to damage to equipment.



Use the screws which length does not exceed the effective depth of screw thread in the table when securing a load. If the screw is longer than the effective depth of screw thread, the screw tip will contact the linear guide, resulting in injury or damage to equipment.




■ When using load mounting surface in the ball screw side

● Specification of load mounting holes

Model	Nominal size	Tightening torque	Effective depth of screw thread
DR20	M2	0.4 N·m (56 oz-in)	4 mm
DR28	M3	1 N·m (142 oz-in)	6 mm

● Installation method

1. Retract the ball screw until the stopper stops.
2. Secure the load with screws (not included).



Do not detach the table or loosen the screws of the table. Doing so may decrease the installation accuracy of the ball screw, resulting in malfunction or shorter service life of the cylinder. In the case of the cylinder equipped with the **AZ** Series, the home set in the encoder (ABZO sensor) at the time of shipment may be deviated, and this may cause unexpected movements, leading to damage to equipment.


■ Load positioning pin holes of table

Two types of load-positioning pin holes, which are an elongated hole and a round hole, are provided on the table. If installation repeatability is required when installing a load, use the load-positioning pin holes.

● Specification of load positioning pin holes [Unit: mm]


The same specifications are applied to both the linear guide and ball screw sides.

● Linear guide side



● Ball screw side

Details of section A



Model	Recommended size of positioning pin	Positioning pin hole (round hole)		Positioning pin hole (elongated hole)		
		Diameter	Depth	E	F	Depth
DR20	$\phi 2 \begin{smallmatrix} 0 \\ -0.01 \end{smallmatrix}$	$\phi 2 \begin{smallmatrix} +0.02 \\ 0 \end{smallmatrix}$	3	$2 \begin{smallmatrix} +0.02 \\ 0 \end{smallmatrix}$	1	3
DR28	$\phi 3 \begin{smallmatrix} 0 \\ -0.01 \end{smallmatrix}$	$\phi 3 \begin{smallmatrix} +0.01 \\ 0 \end{smallmatrix}$	2.5	$3 \begin{smallmatrix} +0.01 \\ 0 \end{smallmatrix}$	1	2.5



Be sure to secure the positioning pins to the load side. Pressing the positioning pins into the table may cause the cylinder break.



When mounting the load at a right angle with respect to the table, use only the round positioning pin hole to adjust the angle.

■ Note when installing a load

Although the table type cylinder can receive a load moment, use it less than the specifications. Continuing to operate the cylinder under a load moment exceeding the specified value may cause malfunction or shorter service life of the cylinder. Check the product specifications on p.44.

5-9 Installing the home-sensor set

Our home-sensor set can be installed for the **DR28**.

■ Details of home-sensor set

The following parts are used in the home-sensor set **PADR-SN28T** or **PADR-SP28T**.

Parts	Number of pieces
Sensor Model NPN output: PM-U25 PNP output: PM-U25-P (Panasonic Industrial Devices SUNX Co., Ltd.)	1 pc.
Shielding plate	1 pc.
Sensor plate	1 pc.
M2 Screw with washer (for mounting the sensor)	2 pcs.
M2 Screw (for mounting the shielding plate and sensor plate)	4 pcs.

Note

- Use the home-sensor set in conditions where the motor surface temperature does not exceed 55 °C (131 °F).
- Do not install the home-sensor set while the power is being supplied. Doing so may result in injury or damage to equipment.
- When installing the sensor plate and shielding plate to the cylinder, be sure to use the included screws.
- Install the sensor so as not to contact with the shielding plate.


memo

- The sensor has no special means of protection against disturbance light because it is designed to be incorporated in equipment. If the cylinder is to be used under an incandescent lamp or in conditions that are subject to disturbances from external light, provide the means to prevent such interference.
- Use the sensors after confirming that there is no looseness, play or other abnormality due to vibration, impact, etc.
- To prevent malfunctioning due to the adhesion of dust on the sensors, clean and/or replace the sensors regularly.
- The sensor set can be installed to the opposite side in the figure.

■ Installation method


1. Secure the sensor plate to the sensor plate mounting holes with M2 screws (included) while pressing the sensor plate to the reference surface of the side face of the guide holder.

Tightening torque: 0.15 N·m (21 oz-in)




2. Secure the shielding plate to the shielding plate mounting holes with M2 screws (included) while pressing the shielding plate to the reference surface of the side face of the table.

Tightening torque: 0.15 N·m (21 oz-in)



3. Secure the sensor to the sensor plate using the M2 screws with washer (included).
The sensor position can be adjusted because the sensor mounting holes are $\varnothing 3.2$ mm with respect to the included M2 screws with washer. Adjust the installation position of the sensor so that the sensor can be detected.
Tightening torque: 0.15 N·m (21 oz-in)



4. Connect a power supply to the sensor and check whether it operates properly.
The sensor is lit in orange when the shielding plate is not detected and unlit when it is detected.

■ Connecting the sensor signal

Use output signals of the sensor at 5 to 24 VDC, 50 mA or less. If the current value exceeds 50 mA, connect an external resistor R.


Output operation can be selected from either ON when light is shielded or ON when light is induced. Use either one of them as appropriate.

- Output operation turns ON when light is shielded: Connect white lead wire.
- Output operation turns ON when light is induced: Connect black lead wire.
- Be sure to insulate the unconnected lead wire.


Note

- Wire to separate the sensor lines away from the power lines such as the cable for motor as far apart as possible. If the sensor lines and power lines have to cross, cross them at a right angle.
- Use a common GND for the sensor and driver. Any difference in GND potential will result in a sensor malfunction.

Connection example for NPN output (PADR-SN28T)



Connection example for PNP output (PADR-SP28T)




6 Connection


6-1 Cylinder equipped with the PKP Series

Pin Nos. 2 and 5 are not used.

● Wiring connection diagram



● Pin assignments



Pin number → 6 5 4 3 2 1

■ Applicable connector/lead wire

Cylinder model	Type	Model
DR28	Connector housing	51065-0600 (Molex Incorporated)
	Contact	50212-8XXX (Molex Incorporated)
	Designated crimping tool	63819-0500 (Molex Incorporated)
	Applicable lead wire	<ul style="list-style-type: none"> ● Diameter of the lead wire: The diameter varies depending on the setting current. <ul style="list-style-type: none"> – When the current value is less than 1 A/phase: AWG28 to 24 (0.08 to 0.2 mm²) – When the current value is 1 A/phase or more: AWG26 to 24 (0.14 to 0.2 mm²) – When the current value is 1.5 A/phase or more: AWG24 (0.2 mm²) ● Outer sheath diameter: ø0.8 to 1.4 mm (ø0.031 to 0.055 in.) ● Stripping length of wire insulation: 1.3 to 1.8 mm (0.051 to 0.071 in.)

■ Connection with the **CVD** driver of Oriental Motor

Refer to the table when connecting with the **CVD** driver of Oriental Motor. "Color" in the table shows the colors of lead wires of our connection cable.

CVD driver CN2 Pin No.	Cylinder Pin No.	Color
1	1	Blue
2	3	Red
3	—	—
4	6	Green
5	4	Black

6-2 Cylinder equipped with the **AZ** Series

Refer to the operating manual of the driver for how to connect with the driver and the wiring distance between the cylinder and driver.

7 Inspection and maintenance

7-1 Maintenance item and timing

If the cylinder is operated eight hours a day, perform maintenance according to the applicable period specified in the table. Reduce maintenance intervals accordingly if the operating rate is high such as continuous operation for twenty-four hours.

Maintenance timing	External inspection	External cleaning	Internal inspection
When operated for the first time	○	○	—
A week after initial operation	○	○	○
Every a month thereafter	○	○	○

■ External inspection

Check the items specified in table.

Item	Inspection item	Remedial action
Cylinder	<ul style="list-style-type: none">• Check if any of the screws having installed the cylinder is loose.• Check if any of the screws having installed a load is loose.	Tighten the screws securely.
Cable, connector	<ul style="list-style-type: none">• Check if a damage or stress is applied on the cable.• Check if the connection part between the cylinder and driver is loose.	<ul style="list-style-type: none">• Replace the cable.• Disconnect and reconnect the connector.
Operation	Check if an unusual noise or vibration is generated from a bearing part.	Check the installation of the load and operation speed.

■ External cleaning

Clean the exterior surface of the cylinder whenever necessary.

- Wipe off any dirt and stains using a soft cloth.
- Do not apply compressed air. Dust may enter from a space, resulting in malfunction.
- To remove stubborn stains, wipe the area using a soft cloth moistened with neutral detergent.
- Do not use petroleum solvents, since they will damage the coated surface.

■ Internal inspection

Visually check the items specified in table. Even if the grease has turned brown, lubrication condition is deemed appropriate if the running surface still appears glossy. Refer to "7-2 Applying grease" for how to apply grease.

Item	Inspection item	Remedial action
Ball screw	Check if any of foreign objects such as dust is adhered.	Remove the foreign matter.
	Check if the grease has lost its gloss or has been consumed.	Clean the ball screw with a soft cloth and apply grease.
Linear guide	Check if any of foreign objects such as dust is adhered.	Remove the foreign matter.
	Check if the grease has lost its gloss or has been consumed.	Clean the ball rolling grooves on both sides of the linear guide with a soft cloth, and apply grease.


7-2 Applying grease

All figures show the **DR28**.



Note Wear protective goggles when applying grease. Pay attention to safety and handle the grease carefully by following the instructions provided with that product. If grease gets into the eyes or comes in contact with the skin, immediately flush the area thoroughly with water.


1. Turn the ball screw by hand to draw from the motor.
In the case of the cylinder with adjusting knob, draw the ball screw by turning the adjusting knob.



2. Wipe off the old grease and any dirt completely with a soft cloth, and apply new grease to the lubrication places shown in the figure.

Grease to be used

- Ball screw: AFC grease (THK CO., LTD.)
- Linear guide: for **DR20** Multemp PS No.2 (KYODO YUSHI CO., LTD.)
for **DR28** AFC grease (THK CO., LTD.)




■ For cylinder with ball screw cover

Apply grease to the cylinder with ball screw cover according to the following procedures.




Do not touch the ball screw cover with bare hands. Doing so may cut fingers or the like by the ball screw cover.


1. Turn the ball screw by hand to draw from the motor.
In the case of the cylinder with adjusting knob, draw the ball screw by turning the adjusting knob.
2. Draw the ball screw cover to the end of the ball screw.



3. Wipe off the old grease and any dirt completely with a soft cloth, and apply new grease to the lubrication places shown in the figure.
- Ball screw: AFC grease (THK CO., LTD.)
 - Linear guide: for **DR20** Multemp PS No.2 (KYODO YUSHI CO., LTD.)
for **DR28** AFC grease (THK CO., LTD.)



4. Return the ball screw cover, and check that it can be fit in the guide inside the pilot section.



7-3 Warranty

Check on the Oriental Motor Website for the product warranty.

7-4 Disposal

Dispose the product correctly in accordance with laws and regulations, or instructions of local governments.

8 Troubleshooting

During cylinder operation, the cylinder may fail to function properly due to an improper setting or wiring. When the cylinder cannot be operated properly, refer to the contents provided in this section and take an appropriate action. If the problem persists, contact your nearest Oriental Motor sales office.

Phenomenon	Possible cause	Remedial action
The ball screw does not move with being jammed.	The ball screw was hit against an object to stop.	<p>Return the ball screw at the recommended starting speed shown in the table next. After that, check the following items. If the ball screw does not return, remove the load.</p> <ul style="list-style-type: none"> • Is the screw for mounting a load come loose? • Are the ball screw and the load damaged? • Are the positions of the stopper and the home displaced? • Is the mounting accuracy changed?
The ball screw does not operate at the command speed.	The thrust of the cylinder is not enough against a load.	Reconsider the load.
Malfunction of cylinder.	A load moment exceeding the specification value is applied.	Use the cylinder with a load moment of the specification value or smaller.
The thrust of the cylinder has lowered.	The wiring distance is exceeded the specification value.	<p>Set the distance between the cylinder and driver within the specification value.</p> <p>Cylinder equipped with the PKP Series: 10 m (32.8 ft.) or less</p> <p>Cylinder equipped with the AZ Series: 20 m (65.6 ft.) or less</p>
	The viscosity of the grease was changed.	Refer to "9-2 General specifications" on p.48, and check the operating ambient temperature.

Recommended starting speed

Model	Lead	Recommended starting speed
DR20	1 mm	0.2 mm/s
	1 mm	0.2 mm/s
	2.5 mm	0.5 mm/s

9 Specifications

9-1 Product specifications

- The box (■) in the model name indicates **A** (without additional function) or **N** (with adjusting knob).
- The box (□) in the model name indicates **D** (downward direction), **R** (right direction), or **L** (left direction) representing the cable outlet direction.
- The circle (○) in the model name indicates **-P** (with foot) or **-F** (with flange) representing a mounting plate. ○ is blank for the cylinder without mounting plate.

■ Cylinder equipped with the AZ Series

Cylinder model		DR20T1B02-AZAK□○ DR20T1BC02-AZAK□○
Ball screw lead [mm]		1
Ball screw type		Precision
Repetitive positioning accuracy [mm]	① Tip position	±0.003
	② Upper side	±0.01
Lost motion [mm]		0.02 or less
Minimum travel amount [mm]		0.001
Permissible moment [N·m] *1	Static permissible moment Dynamic permissible moment	M _P : 0.1 M _Y : 0.05 M _R : 0.15
Transportable mass [kg]	Horizontal	0.5
	Vertical	1
Thrust [N]		15
Push force [N]		—
Holding force [N]		15
Stroke [mm]		25
Maximum speed [mm/s] *2		20
Maximum acceleration [m/s ²]		0.2

*1 Ensure a load is below the value of the thrust.

*2 The maximum speed may decrease depending on the ambient temperature or the connection cable length.

DR28T1A03-AZAK□○ DR28T1AC03-AZAK□○	DR28T1B03-AZAK□○ DR28T1BC03-AZAK□○	DR28T2.5B03-AZAK□○ DR28T2.5BC03-AZAK□○
1	1	2.5
Rolled	Precision	Precision
±0.01	±0.003	±0.003
±0.01	±0.005	±0.005
0.05 or less	0.02 or less	0.02 or less
0.001	0.001	0.001
MP: 0.3 M _V : 0.24 M _R : 1.5	MP: 0.3 M _V : 0.24 M _R : 1.5	MP: 0.3 M _V : 0.24 M _R : 1.5
4	4	4
4	4	2
40	40	20
—	—	50
40	40	20
30	30	30
40	40	100
0.2	0.2	0.5

■ Cylinder equipped with the PKP Series


Cylinder model		DR28T2.5B03-P2■K□○ DR28T2.5BC03-P2■K□○
Ball screw lead [mm]		2.5
Ball screw type		Precision
Repetitive positioning accuracy [mm]	① Tip position	±0.003
	② Upper side	±0.005
Lost motion [mm]		0.02 or less
Minimum travel amount [mm]		0.0125 *1
Permissible moment [N·m] *2	Static permissible moment Dynamic permissible moment	M _P : 0.3 M _V : 0.24 M _R : 1.5
Transportable mass [kg]	Horizontal	4
	Vertical	2
Thrust [N]		20
Push force [N]		—
Holding force [N]		20
Stroke [mm]		30
Maximum speed [mm/s] *3		100
Maximum acceleration [m/s ²]		0.5
Rated current [A/phase]		1.5
Voltage [V]		1.77
Winding resistance [Ω/phase]		1.18
Connection method		Bipolar
Inductance [mH/phase]		0.76±20 %

*1 When the base step angle is 1.8°/step.

*2 Ensure a load is below the value of the thrust.

*3 The maximum speed may decrease depending on the ambient temperature or the connection cable length.


- Repetitive positioning accuracy




① is the repetitive positioning accuracy of the tip position of the table.

② is the repetitive positioning accuracy of the upper side (on the linear guide).

- Permissible moment (Horizontal direction)




- Permissible moment (Vertical direction)




- Transportable mass

• Horizontal direction



• Vertical direction



9-2 General specifications

Operating environment	Ambient temperature	0 to +40 °C [+32 to +104 °F] (non-freezing)
	Ambient humidity	85 % or less (non-condensing)
	Altitude	Up to 1,000 m (3,300 ft.) above sea level
	Surrounding atmosphere	No corrosive gas, dust, water or oil
Storage environment, Shipping environment	Ambient temperature	–20 to +60 °C [–4 to +140 °F] (non-freezing)
	Ambient humidity	85 % or less (non-condensing)
	Altitude	Up to 3,000 m (10,000 ft.) above sea level
	Surrounding atmosphere	No corrosive gas, dust, water or oil
Noise level		70 dB (A) or less
Heat resistance class		130 (B)
Insulation resistance		100 MΩ or more when 500 VDC megger is applied between the following places: • Case - Motor windings
Dielectric strength		Sufficient to withstand the following for 1 minute. • Case - Motor windings 0.5 kVAC 50 Hz or 60 Hz

10 Regulations and standards

10-1 CE Marking/UKCA Marking

■ EU EMC Directive/UK EMC Regulation

The EMC test is conducted in a state where the cylinder is connected to the driver. The driver that is combined with the cylinder complies with the EMC Directive/Regulations. Refer to the operating manual of the driver for details.

■ EU RoHS Directive/UK RoHS Regulation

This product does not contain the substances exceeding the restriction values.

10-2 Machinery Directive

The **DR28** and driver are designed and manufactured to be incorporated in general industrial equipment, and a Declaration of Incorporation of Partly Completed Machinery is issued with them according to the Machinery Directive.

Applicable Standards: EN ISO 12100

11 Accessory

■ Home-sensor set

These are sensor sets for **DR28**.

Model	Sensor output
PADR-SN28T	NPN
PADR-SP28T	PNP

12 Dimensions


■ Cylinder equipped with the PKP Series [Unit: mm]

The box (□) in the model name indicates **D** (downward direction), **R** (right direction), or **L** (left direction) representing the cable outlet direction.

The dimension shows the cylinder with adjusting knob.

Mounting plate	Model	Mass [kg (oz.)]
Without mounting plate	DR28T2.5B03-P2AK□ DR28T2.5B03-P2NK□ DR28T2.5BC03-P2AK□ DR28T2.5BC03-P2NK□	0.36 (12.7)
With flange	DR28T2.5B03-P2AK□-F DR28T2.5B03-P2NK□-F DR28T2.5BC03-P2AK□-F DR28T2.5BC03-P2NK□-F	0.39 (13.8)
With foot	DR28T2.5B03-P2AK□-P DR28T2.5B03-P2NK□-P DR28T2.5BC03-P2AK□-P DR28T2.5BC03-P2NK□-P	


● Mounting plate: Without mounting plate




Cable outlet direction

Downward direction	Right direction	Left direction

● Mounting plate: With flange



● Mounting plate: With foot




■ Cylinder equipped with the **AZ Series** frame size 20 mm [Unit: mm]

The box (□) in the model name indicates **D** (downward direction), **R** (right direction), or **L** (left direction) representing the cable outlet direction.

Mounting plate	Model	Mass [kg (oz.)]
Without mounting plate	DR20T1B02-AZAK□ DR20T1BC02-AZAK□	0.18 (6.4)
With flange	DR20T1B02-AZAK□-F DR20T1BC02-AZAK□-F	0.18 (6.4)
With foot	DR20T1B02-AZAK□-P DR20T1BC02-AZAK□-P	0.18 (6.4)

● Mounting plate: Without mounting plate



Downward direction	Right direction	Left direction

Technical drawing of a mechanical assembly. The drawing includes a side view on the left, a front view in the center, and a detail of section E on the right.

Side View: Shows the profile of the assembly. Dimensions include a length of 5 and a total length of 21. The word "Home" is written below the dimension 21.

Front View: Shows the front of the assembly. Dimensions include a width of 37, a central width of 31 ± 0.2 , and a height of 21. A vertical dimension of 16 ± 0.2 is shown. A hole is dimensioned as $\varnothing 3 \begin{smallmatrix} +0.001 \\ 0 \end{smallmatrix}$. Four holes are dimensioned as $4 \times \varnothing 2.5$. A dimension of (13) is shown for the distance from the top edge to the center of the four holes. A feature is labeled "E".

Details of section E: A circular detail view of section E. It shows a hole with a diameter of $3 \begin{smallmatrix} +0.01 \\ 0 \end{smallmatrix}$ and a radius of R. The distance from the center of the hole to the edge is 1.

Technical drawing showing the front and side views of a mechanical assembly, likely a valve or actuator, with dimensions and a detail of section F.

Front View Dimensions:

- Overall width: 16
- Distance from left face to center of first hole: F
- Distance between centers of first and second holes: 9.5 ± 0.2
- Distance between centers of third and fourth holes: 30.5
- Distance from center of fourth hole to right face: 5
- Overall height: 34
- Distance from top face to center of holes: 28 ± 0.2
- Distance from top face to bottom face: 18
- Label "Home" is positioned near the top right corner.

Side View Dimensions:

- Overall width: 16
- Distance from left face to center of first hole: F
- Distance between centers of first and second holes: 9.5 ± 0.2
- Distance between centers of third and fourth holes: 30.5
- Distance from center of fourth hole to right face: 5
- Overall height: 34
- Distance from top face to center of holes: 28 ± 0.2
- Distance from top face to bottom face: 18

Detail of Section F:

Section F shows a cross-section of the assembly with dimensions:


- Overall width: 16
- Distance from left face to center of first hole: F
- Distance between centers of first and second holes: 9.5 ± 0.2
- Distance between centers of third and fourth holes: 30.5
- Distance from center of fourth hole to right face: 5
- Overall height: 34
- Distance from top face to center of holes: 28 ± 0.2
- Distance from top face to bottom face: 18

■ Cylinder equipped with the AZ Series frame size 28 mm [Unit: mm]


The box (□) in the model name indicates **D** (downward direction), **R** (right direction), or **L** (left direction) representing the cable outlet direction.

Mounting plate	Model	Mass [kg (oz.)]
Without mounting plate	DR28T1A03-AZAK□ DR28T1AC03-AZAK□ DR28T1B03-AZAK□ DR28T1BC03-AZAK□ DR28T2.5B03-AZAK□ DR28T2.5BC03-AZAK□	0.39 (13.8)
With flange	DR28T1A03-AZAK□-F DR28T1AC03-AZAK□-F DR28T1B03-AZAK□-F DR28T1BC03-AZAK□-F DR28T2.5B03-AZAK□-F DR28T2.5BC03-AZAK□-F	0.42 (14.8)
With foot	DR28T1A03-AZAK□-P DR28T1AC03-AZAK□-P DR28T1B03-AZAK□-P DR28T1BC03-AZAK□-P DR28T2.5B03-AZAK□-P DR28T2.5BC03-AZAK□-P	


● Mounting plate: Without mounting plate




Cable outlet direction



● Mounting plate: With flange



● Mounting plate: With foot



- Unauthorized reproduction or copying of all or part of this Manual is prohibited.
If a new copy is required to replace an original manual that has been damaged or lost, please contact your nearest Oriental Motor sales office.
- Oriental Motor shall not be liable whatsoever for any problems relating to industrial property rights arising from use of any information, circuit, equipment or device provided or referenced in this manual.
- Characteristics, specifications and dimensions are subject to change without notice.
- While we make every effort to offer accurate information in the manual, we welcome your input.
Should you find unclear descriptions, errors or omissions, please contact your nearest Oriental Motor sales office.
- ***Orientalmotor***, ***αSTEP*** and ABZO sensor are registered trademarks or trademarks of Oriental Motor Co., Ltd., in Japan and other countries.
Other product names and company names mentioned in this manual may be registered trademarks or trademarks of their respective companies and are hereby acknowledged. The third-party products mentioned in this manual are recommended products, and references to their names shall not be construed as any form of performance guarantee. Oriental Motor is not liable whatsoever for the performance of these third-party products.

© Copyright ORIENTAL MOTOR CO., LTD. 2019

Published in August 2025

- Please contact your nearest Oriental Motor office for further information.

ORIENTAL MOTOR U.S.A. CORP.
Technical Support Tel:800-468-3982
8:30am EST to 5:00pm PST (M-F)

ORIENTAL MOTOR (EUROPA) GmbH
Schiessstraße 44, 40549 Düsseldorf, Germany
Technical Support Tel:00 800/22 55 66 22

ORIENTAL MOTOR (UK) LTD.
Blythe Valley Business Park,
Central Blvd Blythe Valley Park,
Solihull B90 8AG, United Kingdom
Tel:+44-1926-671220

ORIENTAL MOTOR (FRANCE) SARL
Tel:+33-1 47 86 97 50

ORIENTAL MOTOR ITALIA s.r.l.
Tel:+39-02-93906347

ORIENTAL MOTOR ASIA PACIFIC PTE. LTD.
Singapore
Tel:1800-842-0280

ORIENTAL MOTOR (MALAYSIA) SDN. BHD.
Tel:1800-806-161

ORIENTAL MOTOR (THAILAND) CO., LTD.
Tel:1800-888-881

ORIENTAL MOTOR (INDIA) PVT. LTD.
Tel:1800-120-1995 (For English)
1800-121-4149 (For Hindi)

TAIWAN ORIENTAL MOTOR CO., LTD.
Tel:0800-060708

SHANGHAI ORIENTAL MOTOR CO., LTD.
Tel:400-820-6516

INA ORIENTAL MOTOR CO., LTD.
Korea
Tel:080-777-2042

ORIENTAL MOTOR CO., LTD.
4-8-1 Higashiueno, Taito-ku, Tokyo
110-8536 Japan
Tel:+81-3-6744-0361
www.orientalmotor.co.jp/ja