

Small Robots OVR 3-axis SCARA Operating Manual

WM-0001E



Thank you for purchasing an Oriental Motor product. This manual describes product handling procedures and safety precautions. Please read the manual thoroughly to ensure safe operation.

- Only qualified personnel of electrical and mechanical engineering should work with the product.
- The product described in this manual is designed and manufactured to be incorporated into general industrial equipment. Do not use it for any other purpose. Oriental Motor Co., Ltd. is not responsible for any compensation for damage caused through failure to observe this warning.
- Use the product correctly after thoroughly reading the section "[Safety precautions](#)" on page 4. In addition, be sure to observe the contents described in warning, caution, and note in this manual.

Safety precautions	4
WARNING	4
CAUTION	6
Preparation	9
Checking the product	9
How to identify the product model	9
Drivers that can be combined	9
Information about nameplate	10
Names of parts	10
Rotation limit mechanical stopper	12
Robot installation	14
Installation location	14
How to unpack	14
Installation method	17
Mounting the end effector	20
Recommended wiring example	21
Connecting the connector type motor	22
Setup	25
How to setup	25
Origin position during setup	25
Maintenance	28
Inspection	28
Warranty	29
Disposal	29
Replacement work	30
1st axis (M1) replacement	31
2nd axis (M2) replacement	32
3rd axis (M3) replacement	35
Specifications	38
Product Specifications	38
General Specifications	38

Accessories	39
Mounting bracket	39

Safety precautions

The precautions described below are intended to ensure the safe and proper use of the product and to prevent the user and other personnel from exposure to the risk of injury. Use the product only after carefully reading and fully understanding these instructions.

In regard to a robot, it is prohibited to start operating the robot (i.e., to operate the device in accordance with the specified purpose) when the machine in which the robot is incorporated does not meet the relevant safety standards. The factory safety manager or safety personnel in charge of the applicable machine must ensure that the machine is operated only by qualified personnel who has expert knowledge on safety, and thereby prevent injury or damage to the machine.

The term “qualified personnel” refers to persons who have received the necessary training or education and have pertinent experience; who are familiar with the relevant standards and regulations; who are authorized by the factory safety manager to engage in the necessary activities; and who have the ability to discern and prevent potential dangers.

Warning

Handling the product without observing the instructions that accompany a “WARNING” symbol may result in serious injury or death.

Caution

Handling the product without observing the instructions that accompany a “CAUTION” symbol may result in injury or property damage.

Note

The items under this heading contain important handling instructions that the user should observe to ensure safe use of the product.

Tip

The items under this heading contain related information and contents to gain a further understanding of the text in this manual.

WARNING

General

- Never use the product for equipment in connection with the maintenance or management of human life or health.
- Do not use the product in explosive or corrosive environments, in the presence of flammable gases, in areas subjected to splashing water, or near combustible materials. Doing so may result in fire or injury.

- Assign qualified personnel having expert knowledge on electrical and mechanical engineering as well as safety to the task of installing, wiring, operating/controlling, inspecting and troubleshooting the product. Handling by unqualified personnel may result in fire, injury, or damage to equipment.
- Conduct a risk assessment in a state where all parts and components including the product have been installed in the equipment. Failure to do so may result in injury or damage to equipment.
- Provide a safety cage that meets the safety distance specified in ISO 13857 so that an operator or other personnel does not enter the movable range of the product while the equipment is operating. Failure to do so may result in injury.
- When teaching, adjusting, or inspecting the product inside the safety cage, take appropriate safety measures according to the results of the risk assessment of the entire equipment. Failure to do so may result in injury.
- Provide appropriate safety measures so that the entire equipment will operate safely in the event of a system failure or malfunction. Failure to do so may result in injury.
- Provide an emergency stop function for the equipment. Failure to do so may result in injury.
- The function and performance of the safety-related control system are appropriately determined according to the results of the risk assessment of the entire equipment. This may result in injury.
- Do not disassemble or modify the product. Doing so may result in injury or damage to equipment.
- Use the product in a condition where the entire equipment complies with relevant international standards such as ISO 12100, ISO 10218-1, ISO 10218-2, national standards, and legal regulations such as occupational health and safety required in each country. Failure to do so may result in injury or damage to equipment.
- Do not install, connect, or inspect/troubleshoot the product while the power is on. When working with the power on state, provide work rules in accordance with the Ordinance on Industrial Safety and Health and take appropriate safety measures. Failure to do so may result in fire, injury, or damage to equipment.
- Do not allow your hands to be caught in moving parts of the product. Doing so may result in injury or damage to equipment.

Installation and wiring

- Since the product is very heavy, make sure that two or more people work together to perform the necessary tasks when transporting or installing it. This may result in injury.
- Wear a helmet, safety shoes, gloves, or other protective equipment when transporting or installing the product. Failure to do so may result in injury.
- Be sure to secure the product itself according to the instructions. Failure to do so may result in injury or damage to equipment.
- Be sure to wire and connect according to the instructions. Failure to do so may result in fire or damage to equipment.
- Install an external fuse, if necessary, to prevent ignition due to a large amount of current flowing from the power supply side.
- Do not pull or forcibly bend the arm section or cable. Also, do not lift the Robot by holding the cable section. Doing so may result in injury or damage to equipment.

Warning for transportation of heavy load

- Make sure that two or more people work together to perform the necessary tasks or use a crane when transporting the product.
- When working with two or more people, clarify the relationship and roles of the primary worker and assistant worker, and transport the product while communicating with each other to ensure safety.
- When using a crane, do not hang loads exceeding the rated load of the crane.
- Consider the cutting load and safety factor of the lifting tool, use a lifting tool suitable for transporting the product. Also check for any damage to the lifting tools.
- Do not ride on loads suspended by the crane.
- Do not leave a crane unattended with a suspended load.
- Do not enter under a crane with a suspended load.

Operation

- Before operating a robot, check the condition of the surrounding area to ensure safety. This may cause injury or damage to equipment.
- Take appropriate safety measures when placing the motor in a non-excitation state. Failure to do so may result in injury or damage to equipment.
- Do not turn off the power or input a signal to place the motor in a non-excitation state during operation. The robot may move unexpectedly, causing injury or damage to equipment.
- When turning on the driver power, make sure there is no signal input from the host controller. The product may start operating unintentionally, causing injury or damage to equipment.
- When operating the product after the driver power supply is turned on or the power to the motor is turned off, adjust the position at low speed to ensure safety. Failure to do so may result in injury or damage to equipment.
- Turn off the power supply of the driver in the event of a power failure. Otherwise, the product may start suddenly when the power is restored, causing injury or damage to equipment.
- If an abnormality occurs in the product, immediately stop operation and turn off the power to the motor that drives the product. Failure to do so may result in injury or damage to equipment.

Maintenance and inspection

- Perform the pre-work (daily) inspection and periodic inspection according to the instructions in this manual, and check that there are no abnormalities in the product and related equipment before working. Failure to do so may result in injury or damage to equipment.

CAUTION

- Do not use the product beyond its specifications. Doing so may result in injury or damage to equipment.

- Keep the area around the product free of combustible materials. Failure to do so may result in fire or a skin burn(s).
- Do not leave anything around the product that would obstruct ventilation. Doing so may result in damage to equipment.
- Use a driver and cable that are connected to the motor only in the specified combination. Failure to do so may result in fire, injury, or damage to equipment.
- When conducting the insulation resistance measurement or the dielectric strength test, be sure to separate the connection between the product and the driver. Failure to do so may result in damage to equipment.
- Take measures against static electricity when handling. Static electricity may cause the encoder (ABZO sensor) of the motor that drives the product or the driver to malfunction or be damaged. This may result in injury or damage to equipment.
- Keep the encoder (ABZO sensor) of the motor away from a strong magnetic field. This may damage to the encoder (ABZO sensor) or cause the product to malfunction. Injury or damage to equipment may result.
- Stop operation if abnormal noise or vibration occurs during operation. Failure to do so may result in injury or damage to equipment.
- Since the motor surface temperature may exceed 70 °C (158 °F) even under normal operating conditions, if the operator is allowed to approach the motor, affix a warning label shown in the figure on a conspicuous place. The surface is hot, and this may cause a skin burn(s).



- To protect the encoder (ABZO sensor), use the motor in a condition where the motor surface temperature does not exceed 80 °C (176 °F). Failure to do so may result in damage to equipment.
- Make sure not to apply a strong shock to the encoder (ABZO sensor) of the motor. This may damage to the encoder (ABZO sensor) and cause the product to malfunction, resulting in damage to the equipment. The label shown in the figure is affixed on the motor.



- Be careful not to make any mistakes in the combinations when connecting a motor and a driver. Wiring in the wrong combination may cause unexpected movement. This may result in injury or damage to equipment.
- When installing and wiring, take measures against EMC. Without effective measures to suppress Electromagnetic Interference (EMI) caused by the product or driver to the surrounding control system equipment and Electromagnetic Susceptibility (EMS) generated by the product or driver, the function of your equipment may be seriously affected. Verify EMC compliance with the

completed equipment. This may result in injury or damage to equipment.

- The status of the actuating controls shall be clearly indicated, e.g. power on, fault detected, automatic operation. If an indicator light is used, it shall be suitable for its installed location and its color shall meet the requirement of IEC 60204-1.
- Be careful not to get your fingers caught by the stopper (1 place) that limits the movement of the product's 1st axis (M1). Failure to do so may result in injury. The label shown in the figure is affixed on the stopper part.



- Hold the cover firmly to prevent it from falling, when removing the tape from the cover. Failure to do so may result in injury or damage to equipment.
- Be sure to attach the cover after wiring. Failure to do so may result in injury or damage to equipment.

Preparation

Checking the product

Verify that the items listed below are included. Report any missing or damaged items to the Oriental Motor sales office from which you purchased the product.

OVR3041K3-H

- Robot ... 1 unit
- Positioning pin for origin setting ... 1 piece
- Unpacking procedure ... 1 copy

OVR3046K10-H and OVR3070K3-H

- Robot ... 1 unit
- Mechanical stopper ... 1 piece
- Cover screws ... 12 Pieces
- Positioning pin for origin setting ... 1 piece
- Unpacking procedure ... 1 copy

How to identify the product model

Verify the model name of the purchased product against the model shown on the nameplate of the product.

OVR 3 041 K 3 - H
 1 2 3 4 5

1	Number of axes	3: 3 axes
2	Reach length	041: 410 mm (16.14 in.) 046: 460 mm (18.11 in.) 070: 700 mm (27.56 in.)
3	Power Supply Specification	K: 24 VDC
4	Transportable mass	3: 3 kg (6.6 lb.) 10: 10 kg (22 lb.)
5	Robot type	H: SCARA

Drivers that can be combined


Series	Type	Model
AZ Series	Built-in controller type	AZD-KD
	mini Driver RS-485 communication type	AZD-KR2D

Information about nameplate

The figure shows an example.

Tip

The position describing the information may vary depending on the product.




Names of parts

The robot consists of three axes: 1st axis (M1), 2nd axis (M2), and 3rd axis (M3). All motors are of the AZ Series equipped with a battery-free absolute encoder (ABZO sensor). All motors are of the AZ Series equipped with a battery-free absolute encoder (ABZO sensor).


The robot has no mechanism to hold the arm. The arm can be moved manually when the power supply to the robot is turned off due to an emergency stop.

OVR3041K3-H



Axis	Axis name	Component products model
1st axis	M1	DGB130R36-AZAKHL
2nd axis	M2	DGR85R36-AZAKHR
3rd axis	M3	DGR60R30-AZAKU

OVR3046K10-H/OVR3070K3-H




Axis	Axis name	Component products model
1st axis	M1	DGB130R36-AZAKHL
2nd axis	M2	DGR85R36-AZAKHR
3rd axis	M3	DGR60R30-AZAKR

Rotation limit mechanical stopper

OVR3041K3-H


1st axis (M1)

The first axis (M1) has a mechanical stopper that limits the range of movement of the product.



2nd axis (M2)

A mechanical stopper is not included with the 2nd axis (M2). If necessary, use the versatile tapped hole on the arm to install a mechanical stopper.




OVR3046K10-H and OVR3070K3-H


1st axis (M1)

The included mechanical stopper is for the 1st axis (M1). If necessary, install a mechanical stopper using a hex key.

Tightening torque: 2.2 N·m (310 oz-in)



Install the mechanical stopper so that it is below the specified value shown in the figure.



Note

- The height of the mechanical stopper must be less than the specified value shown in the figure. If the specified value is exceeded, the mechanical stopper may hit the case of the 1st axis (M1), causing damage to the product.
- If the 1st arm is stopped by hitting it against the mechanical stopper, the mechanical stopper may loosen. When the 1st arm is stopped by hitting it against the mechanical stopper, check the tightening torque of the mechanical stopper.

2nd axis (M2)

A mechanical stopper is not included with the 2nd axis (M2). Set the limit on the software side as necessary.

Robot installation

Installation location

The product described in this manual is designed and manufactured to be incorporated into general industrial equipment. Install it in a well-ventilated location that provides easy access for inspection.

The location must also satisfy the following conditions:

- Inside an enclosure installed indoors (provide ventilation holes)
- Operating ambient temperature: 0 to +40 °C (+32 to 104 °F) (non-freezing)
- Operating ambient humidity: 85 % or less (non-condensing)
- Area free of explosive atmosphere, toxic gas (such as sulfuric gas), or liquid
- Area not exposed to direct sun
- Area free of excessive amount of dust, iron particles, or the like
- Area not subject to splashing water (rain, water droplets), oil (oil droplets), or other liquids
- Area free of excessive salt
- Area not subject to continuous vibration or excessive shocks
- Area free of excessive electromagnetic noise (from welders, power equipment, etc.)
- Area free of radioactive materials, magnetic fields, or vacuum
- Up to 1,000 m (3,300 ft.) above sea level

How to unpack

Note

- Wear protective equipment (helmet, safety shoes, gloves) when working.
- Since the product is very heavy, make sure that two or more people work together to perform the necessary tasks when transporting or installing it.

OVR3041K3-H

1. Place the package on a horizontal, flat surface to unpack.
The product is not in a fixed state in the package. Be careful when handling the product as it may tilt.
2. Take out the cushioning materials and remove the bands (2 places) that secure the product to the reinforcing plate.



3. Take out the product holding the motor of the 1st axis (M1) and the motor of the 2nd axis (M2) with both hands.

When removing, be sure to use both hands to hold the specified positions. Improper holding, such as holding the product with one hand or in a position other than that specified, may cause the axis to move in an unexpected direction, resulting in a fall or injury.



4. Place the product in the installation area and remove the band that secures the arm.

Note

- If the band is removed before placing the product in the installation area, the arm may shift unexpectedly and fingers may be caught in it, which may cause injury.
- When the arm is extended, the center of gravity shifts, and the product may tilt. Work carefully during operation.

OVR3046K10-H, OVR3070K3-H

1. Place the package on a horizontal, flat surface to unpack.
The product is not in a fixed state in the package. Be careful when handling the product as it may tilt.
2. Take out the cushioning materials and accessories.



3. Take out the product holding the motor of the 1st arm with both hands.
When removing, be sure to use both hands to hold the specified positions. Improper holding, such as holding the product with one hand or in a position other than that specified, may cause the axis to move in an unexpected direction, resulting in a fall or injury.




4. Place the product in the installation area and remove the band that secures the arm.

Note

- If the band is removed before placing the product in the installation area, the arm may shift unexpectedly and fingers may be caught in it, which may cause injury.
- When the arm is extended, the center of gravity shifts, and the product may tilt. Work carefully during operation.

About cover

1. The cover is temporarily fixed with tape at the time of shipment. Hold the cover firmly to prevent it from falling, when removing the tape.



2. Be sure to secure the cover using the included screws for the cover.
Tightening torque: 0.6 N·m (85 oz-in)
Specifications of cover screws (included): ultra-low head hexagon socket head cap screw (M3), length under neck 10 mm (0.39 in.), property class 4.8 or more

Note

Observe the specified screw tightening torque. Also, do not insert tools at an angle. Doing so may result in damage to the screws.

Installation method

The product can be installed either frame mounted or ceiling mounted.

Note

- Ensure that there is sufficient work space at the installation site so that teaching and maintenance/inspection can be performed safely.
- Do not loosen or remove any screws on the product. This may result in reduced positioning accuracy or damage to the product.
- Work in a stable condition so that the product does not tilt.
- Install the product on a metal surface of sufficient strength to prevent vibration or twisting of an enclosure in which the product is installed.

Secure the product to the mounting plate using the mounting holes (four places) of the 1st axis (M1)

Provide screw holes in the mounting plate.

Use the positioning pin holes (two places) when positioning the product.


Screws, spring washers, positioning pin, are to be provided by the customer.

The values of the tightening torque are recommended. Tighten the screws to an appropriate torque according to the design conditions of the end effector.

Mounting plate	Thickness	10 mm (0.39 in.) or more
	Material	Steel
Mounting hole	Hole diameter	φ9 mm (φ0.35 in.)
	Nominal size	M8
	Tightening torque	13 N·m (115 lb-in)
Positioning pin holes	Pin hole diameter	$\phi 5_0^{+0.012}$ mm ($\phi 0.1969_0^{+0.0005}$ in.)
	Pin hole depth	5 mm (0.20 in.) (Blind hole)

Frame mounting

The figure shows a OVR3046K10-H.




Note

Be sure to install the product from the top of the mounting plate. It cannot be installed from the bottom.

Ceiling mounting

The figure shows a OVR3046K10-H.




Note

Prepare the top plate and eyebolts by the customer when installing the product at the ceiling mount.

The figure shows the view from the installation surface side.

OVR3041K3-H


Positioning pin hole (Elongate hole)
Width $5^{+0.0120}_0$ mm ($0.1969^{+0.0005}_0$ in.)



OVR3046K10-H, OVR3070K3-H

Positioning pin hole (Elongate hole)

Width $5^{+0.0120}_0$ mm ($0.1969^{+0.0005}_0$ in.)



Positioning pin hole

Mounting holes (4 places)

Mounting the end effector

Install the end effector using the mounting holes (six places) on the 3rd axis (M3), secure the end effector with screws.


Use the positioning pin holes (two places) of the 3rd axis (M3) when positioning the end effector.

The values of the tightening torque are recommended. Tighten the screws to an appropriate torque according to the design conditions of the end effector.

End effector	Material	Steel or aluminum
Mounting hole	Nominal size	M3
	Tightening torque	1.4 N·m (198 oz-in)
Positioning pin holes	Effective depth of screw	6 mm (0.24 in.)
	Pin hole diameter	$\varnothing 4^{+0.012}_0$ mm ($\varnothing 0.1575^{+0.0005}_0$ in.)
	Pin hole depth	6 mm (0.24 in.) (Blind hole)

OVR3041K3-H


Positioning pin holes (2 places)



End effector mounting holes (6 places)

OVR3046K10-H, OVR3070K3-H

Positioning pin holes (2 places)




End effector mounting holes (6 places)

Recommended wiring example

Recommended wiring

The figure shows an image.

1. Wire the cables using the hollow hole.
2. Fix the cable at the positions near the connectors so that the connectors do not move.
3. Wire the cables with sufficient slack to prevent stress.




Note

- The cover of the OVR3046K10-H and OVR3070K3-H is temporarily fixed with tape at the time of shipment. Hold the cover firmly to prevent it from falling, when removing the tape. Refer to [this chapter](#).
- Keep 1 m (3.3 ft) to 10 m (32.8 ft) for wiring distance between a motor and controller. Maintain the wiring distance to shorter than 1 m (3.3 ft) or longer than 10 m (32.8 ft) may result in increase of the electrical noise emitted from the controller.

Connecting the connector type motor

The motors for the 1st axis (M1) and 2nd axis (M2) use a connector type for their cable connections. Connect according to the following steps.




1. Remove the connector cap.

Note

Do not damage the O-ring of the connector when removing the connector cap.

2. Check the position of the connector terminals and connect the connector of the connection cable.

The figure shows an example where the cable outlet direction is opposite to the output shaft direction.



Note

If the locking lever is in a state of being turned up to the 90-degree position or down to the 0-degree position, parts around the locking lever and the connector are in contact with each other, and the connectors cannot be connected.

Locking lever is in 90-degree position



Locking lever is in 0-degree position



3. Turn the locking lever down to the 0-degree position to fix the connector.

Handling of locking lever

- Do not apply excessive force to the locking lever. If the locking lever is damaged, the connector may not be fixed securely.
- After connecting the connector, turn the locking lever down securely to the 0-degree position to fix the connector.

Warning

Be sure to turn down the locking lever. If the connector is not fixed, the cable may come off, resulting in fire, electric shock, or damage to equipment.

Removing the cable

Turn up the locking lever and pull out the connector.

Tip

Turning up the locking lever to the 90-degree position simultaneously disconnects the connector.

Setup

How to setup

Set the information of the robot with the MRC Studio programming software.


1. Start the MRC Studio software.
2. Click [Communication port] , select a connected controller.
3. Click [Setup] on the start screen.
4. Set the robot type and the mechanism information according to the instructions on the screen.

Origin position during setup

OVR3041K3-H

This product has positioning pin holes (2 places) for origin setting. Use the positioning pin holes when aligning the 1st arm and 2nd arm.


Pin hole diameter: $\varnothing 4^{+0.018}_0$ mm ($\varnothing 0.1575^{+0.0007}_0$ in.)




OVR3046K10-H, OVR3070K3-H

This product has positioning pin holes (4 places) for origin setting. Use the positioning pin holes when aligning the motor of the 1st axis (M1) and the 1st arm, and the 1st arm and the 2nd arm.

Pin hole diameter: $\varnothing 4^{+0.018}_0$ mm ($\varnothing 0.1575^{+0.0007}_0$ in.)




1. Fold the 1st arm and align the motor of the 1st axis (M1) and the 1st arm using the included positioning pin for origin setting.



2. Remove the positioning pin.

3. Fold the 2nd arm and align the 1st arm and the 2nd arm using the included positioning pin for origin setting.

Secure it with the included positioning pin for origin setting



Note

Turn off the power supply of the robot when the arm is moved manually. However, if the arm is operated beyond the movable angle range based on the arm position at the time of setup, an alarm of joint angle range error will be generated when the power supply of the robot is turned on.

- Movable angle range
 - 1st arm: $\pm 360^\circ$
 - 2nd arm: $\pm 170^\circ$

Maintenance

Assign qualified personnel with sufficient knowledge and experience to perform daily and periodic inspections in accordance with the “Safety Precautions” section.

Be sure to perform these inspections in order to prevent malfunctions in advance and to ensure safety, and check that there are no abnormalities in the product and related equipment before operation. If any abnormality is found, discontinue use immediately and take necessary action, such as repair.

Inspection

Inspection Period (Cycle)

Perform maintenance for each time period shown in the table when operating eight hours per day. Shorten the maintenance cycle depending on the situation when the product is operated continuously day and night or when the operating rate is high.

Maintenance timing	Inspection	Cleaning
When operated for the first time	○	—
Six months after initial operation	○	—
Every six months thereafter	○	—
As needed	—	○

Inspection items

- Check to see if the position securing the product is loose.
- Check to see if any of the screws securing the end effector are loose.
- Check to see if the cable is damaged, scraped or stressed.
- Check to see if the connection between the motor and driver is loose.
- Before and after the power is turned on, check to see if there is any abnormal noise or vibration coming from the bearing or gears.
- Check to see if the operating point has shifted during return-to-home operation and normal operation (original program operation).

Note

- Enter the inspection results and any special comments on the daily checklist when the inspection is performed.
- Perform the inspection outside of the movable range as much as possible.
- If the product has been repaired as a result of the inspection, keep a record of the contents for at least three years.

Tip

Replace the cable if the cable has been abraded as a result of the inspection.

Cleaning

- Wipe off dirt with a soft cloth. If it is very dirty, wipe with a soft cloth with neutral detergent.
- Do not blow with compressed air. Dust may enter through the gap.
- Do not use petroleum-based solvents as they may damage the painted surface.

Warranty

Check on the Oriental Motor Website.

Disposal


Dispose the product correctly in accordance with laws and regulations, or instructions of local governments.

Replacement work

Note


Do not remove or loosen any screws other than those specified for the replacement work. This may result in reduced positioning accuracy or damage to the product.

Removable screws




Non-removable screws

Do not remove or loosen the following screws. AS an example, the figure shows the motor section of the 1st axis (M1).




1st axis (M1) replacement


This explains how to use by taking the OVR3046K10-H as an example.



1. Remove the screw that secures the cover on the 1st arm and remove the cover.
2. Remove the Screws (6 pieces) securing the 1st arm and 1st axis (M1) then remove the 1st arm.




3. Using the pilot of the 1st arm as a guide, secure the 1st arm to the new 1st axis (M1) and tighten the screws (6 pieces).
Tightening torque: 3.5 N·m (490 oz-in)




4. After replacement, the setup will be performed again.
5. Attach the movable cover and tighten the screws.
Tightening torque: 0.6 N·m (85 oz-in)

2nd axis (M2) replacement


This explains how to use by taking the OVR3046K10-H as an example.



1. Remove the screw securing the cover of the 1st arm and the 2nd arm then remove the each cover.
2. Remove the Screws (6 pieces) securing the 2nd arm and 2nd axis (M2) then remove the 2nd arm.



3. Remove the Screws (4 pieces) securing the 2nd axis and the 1st arm then remove the 2nd axis (M2).




Note


This product requires working from the underside. Hold the 2nd arm and the 2nd axis (M2) firmly to prevent them from dropping.

4. Insert the positioning pins (2 pieces) into the new 2nd axis (M2).
Positioning pins are to be provided by the customer.

Positioning pin hole diameter	$\varnothing 5_0^{+0.012}$ mm ($\varnothing 0.1969_0^{+0.0005}$ in.)
Positioning pin hole depth	15 mm (0.59 in.)




5. Using the positioning pin as a guide, secure the new 2nd axis (M2) to the 1st arm and tighten the screws (4 pieces).
Tightening torque: 6 N·m (850 oz-in)



Note

This product requires working from the underside. Securely hold the 2nd arm and the 2nd axis (M2) to prevent them from dropping.


6. Remove the positioning pin.
7. Using the pilot of the 2nd arm as a guide, secure the 2nd arm to the new 2nd axis (M2) and tighten the screws (6 pieces).
Tightening torque: 2 N·m (280 oz-in)




8. After replacement, the setup will be performed again.
9. Attach the movable cover and tighten the screws.
Tightening torque: 0.6 N·m (85 oz-in)

3rd axis (M3) replacement


This explains how to use by taking the OVR3046K10-H as an example.



1. Remove the screw that secures the cover on the 2nd arm and remove the cover.
2. Remove the Screws (2 pieces) securing the 3rd axis (M3) and the 2nd arm then remove the 3rd axis (M3).



3. For the OVR3046K10-H and OVR3070K3-H, bend the lead wire of the new 3rd axis (M3) to the opposite side of the table and secure the tube to the motor with the cable tie.
The cable tie is to be provided by the customer.



Note


- Do not secure the lead wires directly.
- Do not excessively bend the lead wires near the connection part of the connector. Applying stress on the lead wires may cause poor contact or disconnection, leading to malfunction or heat generation.

Tip

This step is not required for OVR3041K3-H.

4. Insert the positioning pins (2 pieces) into the new 3rd axis (M3).
Positioning pins are to be provided by the customer.

Positioning pin hole diameter	$\varnothing 5_0^{+0.012}$ mm ($\varnothing 0.1969_0^{+0.0005}$ in.)
Positioning pin hole depth	15 mm (0.59 in.)



5. Using the positioning pin as a guide, secure the new 3rd axis (M3) to the 2nd arm and tighten the two screws.
Tightening torque: 2 N·m (280 oz-in)
6. Remove the positioning pin.
7. After replacement, the setup will be performed again.
8. Attach the movable cover and tighten the screws.
Tightening torque: 0.6 N·m (85 oz-in)

Specifications

Product Specifications

Check on the Oriental Motor Website for the product specifications.

General Specifications

Degree of protection

IP40 (excluding the connector part)

Operating environment

Ambient Temperature: 0 to +40 °C (+32 to +104 °F) (non-freezing)

Humidity: 85 % or less (non-condensing)

Altitude: Up to 1,000 m (3,300 ft.) above sea level

Atmosphere: No corrosive gas or dust. No exposure to water or oil.

Storage Environment and Shipping Environment

Ambient temperature: -20 to +60 °C (-4 to +140 °F) (non-freezing)

Humidity: 85 % or less (non-condensing)

Altitude: Up to 3,000 m (10,000 ft.) above sea level

Atmosphere: No corrosive gas or dust. No exposure to water or oil.


Accessories

Mounting bracket


This can be used for mounting end effectors and lifting axes.

Model	Installation location	Products that can be installed	Included	
			Mounting screw	Positioning pins
PDG60-1	3rd axis (M3)	EH3-AZAKH	M3×8 mm (0.31 in.) (10 pieces)	φ3×5.8 mm (φ0.12×0.23 in.) (2 pieces) φ4×9 mm (φ0.16×0.35 in.) (2 pieces)
PDG60-2		EH4-AZAKH	M3×8 mm (0.31 in.) (6 pieces) M4×8 mm (0.31 in.) (4 pieces)	
PDG60-3*1		DR28T, EH3-AZAKH	M2.5×10 mm (0.39 in.) (4 pieces) M3×8 mm (0.31 in.) (12 pieces)	φ3×5.8 mm (φ0.12×0.23 in.) (4 pieces) φ4×9 mm (φ0.16×0.35 in.) (2 pieces)
PDG60-4*1		DR28T, EH4-AZAKH	M2.5×10 mm (0.39 in.) (4 pieces) M3×8 mm (0.31 in.) (8 pieces) M4×8 mm (0.31 in.) (4 pieces)	
PDG60-5 *2 *3		AZM24AK-CSF8, P3F1, P3F2	M3×5 mm (0.2 in.) (6 pieces) M3×8 mm (0.31 in.) (10 pieces) M3×25 mm (0.98 in.) (4 pieces) M4×8 mm (0.31 in.) (4 pieces)	φ3×5.8 mm φ0.12×(0.23 in.) (2 pieces) φ4×9 mm (φ0.16×0.35 in.) (2 pieces)
PDG130-6	1st axis (M1)	EGC-HD-125-BS (Festo K.K.)	M5×15 mm (0.59 in.) (24 pieces) M8×15 mm (0.59 in.) (3 pieces) M8×25 mm (0.98 in.) (4 pieces)	φ5×8 mm (φ0.20×0.31 in.) (6 pieces)
PDG130-7		SKR46A (THK CO., LTD.)	M5×15 mm (0.59 in.) (8 pieces) M6×16 mm (0.63 in.) (4 pieces) M8×15 mm (0.59 in.) (3 pieces) M8×25 mm (0.98 in.) (4 pieces)	φ5×8 mm (φ0.20×0.31 in.) (4 pieces)

*1 When combined with OVR3046k10-H or OVR3070K3-H, the DR series is moved to the maximum stroke, the EH series may interfere with the 1st arm.



*2 Ensure the lead wire outlet direction downward when installing the motor (AZM24AK) on the PDG60-5. If installed in any direction other than downward, the encoder part may interfere with the arm.



*3 This product cannot be used with OVR3046K10-H and OVR3070K3-H.

Specifications of mounting holes and positioning pin holes

Model	Mounting hole				Positioning pin holes	
	Hole diameter	Nominal size	Screw length	Tightening torque	Pin hole diameter	Pin hole depth
PDG60-1	φ3.4 mm (φ0.13 in.)	M3	8 mm (0.31 in.)	1 N·m (142 oz-in)	$\phi 3_0^{+0.014}$ mm $(\phi 0.1181_0^{+0.0006}$ in.) $\phi 4_0^{+0.018}$ mm $(\phi 0.1575_0^{+0.0007}$ in.)	3 mm (0.12 in.) (Blind hole) 4 mm (0.16 in.) (Blind hole)
PDG60-2	φ3.4 mm (φ0.13 in.)	M3	8 mm (0.31 in.)	1 N·m (142 oz-in)		
	φ4.5 mm (φ0.18 in.)	M4	8 mm (0.31 in.)	2 N·m (280 oz-in)		
PDG60-3	φ2.9 mm (φ0.11 in.)	M2.5	10 mm (0.39 in.)	0.5 N·m (71 oz-in)		
	φ3.4 mm (φ0.13 in.)	M3	8 mm (0.31 in.)	1 N·m (142 oz-in)		
PDG60-4	φ2.9 mm (φ0.11 in.)	M2.5	10 mm (0.39 in.)	0.5 N·m (71 oz-in)		
	φ3.4 mm (φ0.13 in.)	M3	8 mm (0.31 in.)	1 N·m (142 oz-in)		
	φ4.5 mm (φ0.18 in.)	M4	8 mm (0.31 in.)	2 N·m (280 oz-in)		
PDG60-5	φ3.4 mm (φ0.13 in.)	M3	5 mm (0.20 in.)	1 N·m (142 oz-in)		
	φ3.4 mm (φ0.13 in.)	M3	5 mm (0.20 in.)	1 N·m (142 oz-in)		
	φ3.4 mm (φ0.13 in.)	M3	25 mm (0.98 in.)	1 N·m (142 oz-in)		
	φ4.5 mm (φ0.18 in.)	M4	8 mm (0.31 in.)	2 N·m (280 oz-in)		
PDG130-6	φ5.5 mm (φ0.22 in.)	M5	15 mm (0.59 in.)	3 N·m (420 oz-in)	$\phi 5_0^{+0.018}$ mm $(\phi 0.1969_0^{+0.0007}$ in.)	4 mm (0.16 in.) (Blind hole)
	φ9 mm (φ0.35 in.)	M8	15 mm (0.59 in.)	12 N·m (106 lb-in)		
	φ9 mm (φ0.35 in.)	M8	25 mm (0.98 in.)	12 N·m (106 lb-in)		
PDG130-7	φ5.5 mm (φ0.22 in.)	M5	15 mm (0.59 in.)	3 N·m (420 oz-in)		
	φ6.6 mm (φ0.26 in.)	M6	16 mm (0.63 in.)	5 N·m (710 oz-in)		
	φ9 mm (φ0.35 in.)	M8	15 mm (0.59 in.)	12 N·m (106 lb-in)		
	φ9 mm (φ0.35 in.)	M8	25 mm (0.98 in.)	12 N·m (106 lb-in)		

- Unauthorized reproduction or copying of all or part of this manual is prohibited.
- Oriental Motor shall not be liable whatsoever for any problems relating to industrial property rights arising from use of any information, circuit, equipment or device provided or referenced in this manual.
- Characteristics, specifications and dimensions are subject to change without notice.
- While we make every effort to offer accurate information in the manual, we welcome your input. Should you find unclear descriptions, errors or omissions, please contact the nearest office.
- The following is a registered trademark or trademark of Oriental Motor Co., Ltd., in Japan and other countries.

Orientalmotor, ABZO sensor

- Other product names and company names mentioned in this manual may be registered trademarks or trademarks of their respective companies and are hereby acknowledged. The third-party products mentioned in this manual are recommended products, and references to their names shall not be construed as any form of performance guarantee. Oriental Motor Co., Ltd. is not liable whatsoever for the performance of these third-party products.

© Copyright ORIENTAL MOTOR CO., LTD. 2025

Published in July 2025

• Please contact your nearest Oriental Motor office for further information.

ORIENTAL MOTOR U.S.A. CORP.
Technical Support Tel:800-468-3982
8:30am EST to 5:00pm PST (M-F)

ORIENTAL MOTOR (EUROPA) GmbH
Schiessstraße 44, 40549 Düsseldorf, Germany
Technical Support Tel:00 800/22 55 66 22

ORIENTAL MOTOR (UK) LTD.
Blythe Valley Business Park,
Central Blvd Blythe Valley Park,
Solihull B90 8AG, United Kingdom
Tel:+44-1926-671220

ORIENTAL MOTOR (FRANCE) SARL
Tel:+33-1 47 86 97 50

ORIENTAL MOTOR ITALIA s.r.l.
Tel:+39-02-93906347

ORIENTAL MOTOR ASIA PACIFIC PTE. LTD.
Singapore
Tel:1800-842-0280

ORIENTAL MOTOR (MALAYSIA) SDN. BHD.
Tel:1800-806-161

ORIENTAL MOTOR (THAILAND) CO., LTD.
Tel:1800-888-881

ORIENTAL MOTOR (INDIA) PVT. LTD.
Tel:1800-120-1995 (For English)
1800-121-4149 (For Hindi)

TAIWAN ORIENTAL MOTOR CO., LTD.
Tel:0800-060708

SHANGHAI ORIENTAL MOTOR CO., LTD.
Tel:400-820-6516

INA ORIENTAL MOTOR CO., LTD.
Korea
Tel:080-777-2042

ORIENTAL MOTOR CO., LTD.
4-8-1 Higashiueno, Taito-ku, Tokyo
110-8536 Japan
Tel:+81-3-6744-0361
www.orientalmotor.co.jp/ja