



Linear Motion Controller

CHECKING THE PRODUCT

Thank you for purchasing an Oriental Motor product.

- Please read the separate manuals entitled OPERATING MANUAL and BEFORE USING THE PRODUCT thoroughly to ensure safe operation of the product.
- Always keep the manual where it is readily available.


Packing list

Verify that the items listed below are included.

Report any missing or damaged items to the branch or sales office from which you purchased the product.

- | | |
|--|--|
| • Linear motion controller 1 unit | • Controller mounting bracket flat-head screws (M3)....4 pcs. |
| • Controller mounting brackets 2 pcs. | • <u>CHECKING THE PRODUCT</u> (This manual).....1 copy |
| • User I/O connector (36 pins) 1 set | • <u>BEFORE USING THE PRODUCT</u>1 copy |
| • Sensor I/O connector (20 pins) 1 set | • <u>Linear Motion Controller OPERATING MANUAL</u>1 copy |

How to identify the product model



- Please contact your nearest Oriental Motor office for further information.

ORIENTAL MOTOR U.S.A. CORP.
Technical Support Line Tel:(800)468-3982
Available from 7:30 AM to 5:00 PM, P.S.T.
E-mail: techsupport@orientalmotor.com
www.orientalmotor.com

ORIENTAL MOTOR (EUROPA) GmbH
Headquarters and Düsseldorf Office
Tel:0211-5206700 Fax:0211-52067099
Munich Office
Tel:08131-59880 Fax:08131-598888
Hamburg Office
Tel:040-76910443 Fax:040-76910445
ORIENTAL MOTOR (UK) LTD.
Tel:01256-347090 Fax:01256-347099
ORIENTAL MOTOR (FRANCE) SARL
Tel:01 47 86 97 50 Fax:01 47 82 45 16
ORIENTAL MOTOR ITALIA s.r.l.
Tel:02-93906346 Fax:02-93906348

TAIWAN ORIENTAL MOTOR CO.,LTD.
Tel:(02)8228-0707 Fax:(02)8228-0708

SINGAPORE ORIENTAL MOTOR PTE LTD
Tel:(6745)7344 Fax:(6745)9405

ORIENTAL MOTOR (MALAYSIA) SDN. BHD.
Tel:(03)22875778 Fax:(03)22875528

INA ORIENTAL MOTOR CO.,LTD.
KOREA
Tel:(032)822-2042~3 Fax:(032)819-8745

ORIENTAL MOTOR CO.,LTD.
Headquarters Tokyo, Japan
Tel:(03)3835-0684 Fax:(03)3835-1890